

7-10 DIA. WHEELS FROM LAWNMOWER, WAGON, TRICYCLE, BARBECUE, ETC.

POST - 2x4

SEAT BACK - 8 3/4 x 20 7/8 PLYWOOD

SEAT 15 x 20 7/8 PLYWOOD

SQUARE SECTION PREVENTS TURNING.

CARRIAGE BOLT

LAG SCREW

MACHINE BOLT

USE THESE TYPE FASTENERS - NAILS WILL NOT HOLD.

FRAME - 2x4 52 LONG

STEERING BRIDLE - 1/4" NYLON ROPE

WHEEL

AXLE

LAG SCREW

FLAT WASHER

FLAT WASHER

AXLES - 2x4, 28 LONG

FLAT WASHER

DRILL HOLES

FRAME

2 FLAT WASHERS

FRONT AXLE

WASHER

NUT

SECOND NUT TIGHTENED AGAINST FIRST TO LOCK

SAFETY BLOCKS TO LIMIT STEERING ANGLE

USE SAFETY BELTS AND HELMETS.

PLYWOOD BRACE - ONE EACH SIDE

15 1/2

12

BRAKE

5" NAIL STRIP OF OLD TIRE TO BRAKE.

2 CARRIAGE BOLTS

48 WHEELBASE

